



FIG. 3.17 Examples of correct and incorrect welding practice for vacuum applications (from Kronberger 1958).