



FIG. 4.4 Illustration of noninductive winding scheme for further minimizing induced voltages in instrumentation leads when making measurements in high magnetic fields.