



FIG. 4.7 When attaching a bare copper wire to a copper block, make sure that the wire is in direct contact with the block, not between washers, as is common, for example, with telephone-wire connectors. Clean the wire and the block with Scotch-Brite® to remove the surface oxide.