



Fig. 7.8 Noninductive winding scheme, where one of the voltage leads is wound counter to the test sample to minimize the loop area and induced electromagnetic noise.