



FIG. 8.15 Configurations for measuring film interface resistivity: (a) crossover configuration, for simplicity in patterning; and (b) window configuration, to minimize sheet-resistance effects in normal-metal overlayers [(b) from Cohen and Gildenblat 1986].